

Warning

IMPORTANT SAFETY INSTRUCTIONS

When using this product, basic safety precautions should always be followed to reduce the risk of injury including the following:

WARNING

Risk of injury! Unassembled product contains small parts, sharp edges and sharp points. Keep all parts out of reach of children and pets.

WARNING

Risk of injury! Always use the product with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.

CAUTION

Risk of injury! Toy is to be assembled by an adult.

- The product should always be used under adult supervision.
- Before riding, instruct the child on how to use the product.
- Children should always wear suitable clothing/footwear while using the product.
Gloves, elbow pads and knee pads are also recommended.
- The product can only carry one child at a time.
- Intended for use by children aged 18 months - 6 years old. Size and weight of children can vary. Ensure that the child's feet can safely touch the ground before use.
- This product can be used only by a skilled person.
- Do not use the product near motor vehicles, on hills, near swimming pools and any other potentially hazardous locations.
- Ensure the product is used in a safe riding area, e.g a closed park.

BEFORE FIRST USE

DANGER

Risk of suffocation! Keep any packaging materials away from children - these materials are a potential source of danger, e.g. suffocation.

- Check the product for transport damages.
- Remove all packing material and check if all parts are included.
- Before first use, make sure the product is properly and safely assembled.
- Inflate tire before first use.
- If there is no air in the tube, and the tire is not in correct position, please always wiggle the tire into the correct position and then fill it with air.

ADJUSTING SEAT HEIGHT

1. Release the lever on the seat clamp and turn the screw anticlockwise to loosen the seat post.
2. Adjust the height of the seat making sure at least 2.5 inch of the seat tube is inside the seat post.
3. Fasten the seat clamp by turning the screw clockwise until snug, then press the lever down to lock the seat in place.

CLEANING AND MAINTENANCE

- To clean the product, wipe with a slightly damp cloth. dry the product after cleaning.
- Regular checks should be carried out ensuring all screws are tightened.
- The product should be stored in a dry place.

MANUAL INSTRUCCIONS

You can find a tutorial video here:

<https://youtu.be/jodQo3JSMal>

